

Plug-in Raceway Modules Instructions and Details

WARNING: Hazardous voltage will cause severe shock or burn. Ensure that all circuit breakers are in the 'OFF' position before installing onto the raceway.

To install the module onto the raceway, insure proper alignment with the raceway so that the breaker/label side is facing down. The breaker/label side of the modules should match the polarizing stripe of the backplane (Fig 2). Place the top leg of the plug-in module onto the backplane (fig 1), making sure that there is contact, rotate the module (Fig 3) until the lower leg makes contact with the backplane. You will hear a click. The plug-in module is now installed (Fig 4).

To remove the plug-in module, press in the oval buttons (Detail A) on the bottom of the module to release the latching snaps, pulling out and rotating up, the module will release from the backplane.

WARNING: Modules may be installed on an energized system. Be sure that they are NOT installed under load.

